



NOTE: INSTALL A MINIMUM 2" DIAMETER PLASTIC OR P.V.C. TYPE PIPE UNDER CONCRETE 12" BEHIND CURB, 18" DEEP. CAP OR PLUG ENDS, BACK FILL WITH GRANULAR MATERIAL.

NOTE: FOR REMOVAL OF CURB BACK FOR DRIVEWAY OPENING REFER TO SECTION 3.9 OF FRANKLIN DESIGN STANDARD AND CONSTRUCTION SPECIFICATIONS

# TYPICAL FLARED DRIVEWAY APPROACH — MOUNTABLE CONCRETE CURB

DRAWN BY TEG

APPROVED BY \_\_\_\_\_

FRANKLIN  
ENGINEERING DEPT.

NOT TO SCALE

FIGURE 13